

## Bed Assembly

|    |            |                      |              |   |
|----|------------|----------------------|--------------|---|
| 1  | JJ-T01     | Base                 |              | 1 |
| 2  | JJ-T02     | Front Table          |              | 1 |
| 3  | JJ-T03     | Rear Table           |              | 1 |
| 4  | JJ-T04     | Gib                  |              | 2 |
| 5  | JH-T30     | Lock Screw           | 1/4-20x1     | 2 |
| 6  | TS-0267091 | Set Screw            | 1/4-20x1     | 4 |
| 7  | TS-0561011 | Hex Nut              | 1/4-20NC     | 2 |
| 8  | JJ-T07     | Ball Crank           |              | 1 |
| 9  | JJ-T06     | Shoulder Pin         |              | 2 |
| 10 | TS-0680061 | Washer               | 1/2          | 2 |
| 11 | TS-0561051 | Hex Nut              | 1/2-12NC     | 2 |
| 12 | JH-T11     | Pivot Pin            |              | 2 |
| 13 | JH-T13     | Handle Shaft Bolt    |              | 2 |
| 14 | JH-T14     | Handle               |              | 2 |
| 15 | JH-T15     | Handle Wheel         |              | 2 |
| 16 | TS-0267011 | Set Screw            | 1/4-20x1/4   | 2 |
| 17 | JH-T16     | Bushing              |              | 2 |
| 18 | JH-T17     | Washer               |              | 4 |
| 19 | JH-T18     | Adjusting Nut        |              | 2 |
| 20 | JH-T19     | Adjusting Screw      |              | 2 |
| 21 | 5F-E108    | Pin                  | 3x24         | 2 |
| 22 | JH-T20     | Lock Knob            |              | 2 |
| 23 | JH-T21     | Lock Knob            |              | 2 |
| 24 | TS-0270031 | Set Screw            | 5/16-18x3/8  | 2 |
| 25 | JH-T12     | Ball Crank           |              | 1 |
| 26 | JH-T22     | Cutterhead Guard     |              | 1 |
| 27 | JH-T23     | Guard Post           |              | 1 |
| 28 | JH-T24     | Retaining Washer     |              | 1 |
| 29 | JH-T25     | Spring               |              | 1 |
| 30 | JH-T26     | Spring Knob          |              | 1 |
| 31 | JH-T27     | Retainer             |              | 1 |
| 32 | 5C-D006    | Screw                |              | 3 |
| 33 | JC-T17     | Pointer              |              | 1 |
| 34 | 5F-H051    | Rivet                | 2x5          | 7 |
| 35 | JJ6-19     | Depth Scale          |              | 1 |
| 36 | JJ6-01CS   | Warning Label        |              | 1 |
| 37 | JJ6-02CS   | Name Plate           |              | 1 |
| 38 | JEJ-B14    | Fence Base Casting   |              | 1 |
| 39 | JED-B02    | Key                  |              | 1 |
| 40 | 5FF-J12    | Spring Pin           |              | 1 |
| 41 | TS-0680041 | Washer               | 3/8          | 1 |
| 42 | Ts-0680041 | Washer               | 3/8          | 1 |
| 43 | TS-0209071 | Hex Socket Cap Screw | 3/8 x 1-1/2  | 2 |
| 44 | JEI-B05    | 1/8" Set Block       |              | 1 |
| 45 | JEA-B06    | Stud                 | 1/4-20       | 1 |
| 46 | JEA-B08    | Spring               |              | 1 |
| 47 | JEA-B09    | Stud                 | 1/12-12      | 1 |
| 48 | 5DF-B05    | Knob                 | 1/4-20       | 1 |
| 49 | 5CO-D09B   | Lock Handle          | 1/4-20 x 7/8 | 1 |
| 50 | TS-0208041 | Hex Socket Cap Screw | 5/16 x 3/4   | 3 |
| 51 | 708815     | Push Blocks          |              | 2 |

